



CUT-OFF END REPAIR:

1. Cut end of stone to the desired length
2. Scrape sides of stone on the inside down to 1 1/2"
3. Take all the foam out at a depth of 1 1/2"
4. Clean the inside of 1 1/2" walls to create bonding of new material
5. Drill 3/8" deep x 3/8" diameter holes 6" on center around perimeter of inside to create dowels
6. Pour Piazza mix into 1 1/2" recessed area to the level on the end
7. Let sit for 48 hours
8. Ready to install

DATE:	PROJECT:
2-26-2021	
SHT. No.	

HOW TO REPAIR CUT-OFF ENDS



3817 Martinez Blvd. Ste. A
 Augusta, GA 30907
 706-651-1210